

NAME	DESCRIPTION
K1	Safety relay
S1	Pilot ON/OFF switch - 8-way connector
S2	Gearshift configuration switch - 8-way connector
X1	Valve configuration "1" - 2-way connector
X2	Valve configuration "2" - 2-way connector
X4	Left hydraulic control lever - 2-way connector
X11	Left stabilizer pressure switch - 2-way connector
X12	Right stabilizer pressure switch - 2-way connector
X13	Right towing line - 5-way connector
X14	Right hydraulic control lever - 6-way connector
X17	Manifold power - 2-way connector
X20	Control unit - 23-way connector
X23	Safety switch - 2-way connector
X24	Left stabilizer control lever - 6-way connector
X27	Horn jumper connection - 2-way connector
X72	Pilot control cable - 1-way connector
XL	Left stabilizer control lever - 3-way connector
XR	Right stabilizer control lever - 3-way connector
YP3	Left bottom plug 3 - 2-way connector
YP4	Left top plug 4 - 2-way connector
YP5	Right bottom plug 5 - 2-way connector
YP6	Right top plug 6 - 2-way connector
YP7	Extension plug 7 - 2-way connector
YP8	Retraction plug 8 - 2-way connector
YP9	Reverse travel auxiliary speed plug 9 - 2-way connector
YP10	Auxiliary forward travel plug 10 - 2-way connector